



SINGLE TAB SPOTWELD NUT

Thread Size	Width	Width Tolerance	Thickness	Thickness Tolerance	Length	Length Tolerance	Pilot Diameter	Pilot Tolerance	Pilot Height	Pilot Tolerance
#6-32	0.438	+0.015 -0.005	0.094	+0.003 -0.003	0.625	+0.015 -0.015	0.188	+0.010 -0.010	0.030	0.203
#8-32	0.438	+0.015 -0.005	0.094	+0.003 -0.003	0.625	+0.015 -0.015	0.203	+0.010 -0.010	0.030	0.219
#10-24	0.438	+0.015 -0.005	0.094	+0.003 -0.003	0.625	+0.015 -0.015	0.234	+0.010 -0.010	0.030	0.250
#10-32	0.438	+0.015 -0.005	0.094	+0.003 -0.003	0.625	+0.015 -0.015	0.234	+0.010 -0.010	0.030	0.250
1/4-20	0.500	+0.020 -0.005	0.125	+0.003 -0.003	0.813	+0.014 -0.016	0.297	+0.010 -0.010	0.050	0.312
1/4-28	0.500	+0.020 -0.005	0.125	+0.003 -0.003	0.813	+0.014 -0.016	0.297	+0.010 -0.010	0.050	0.312
5/16-18	0.625	+0.030 -0.005	0.141	+0.004 -0.002	0.984	+0.015 -0.015	0.359	+0.010 -0.010	0.080	0.375
5/16-24	0.625	+0.030 -0.005	0.141	+0.004 -0.002	0.984	+0.015 -0.015	0.359	+0.010 -0.010	0.080	0.375
3/8-16	0.625	+0.030 -0.005	0.141	+0.004 -0.002	1.125	+0.015 -0.015	0.438	+0.010 -0.010	0.090	0.453
3/8-24	0.625	+0.030 -0.005	0.141	+0.004 -0.002	1.125	+0.015 -0.015	0.438	+0.010 -0.010	0.090	0.453

800-458-9353

www.hybrocosales.com